



Sport-Wick® Fleece Flex Full-Zip Jacket

PRODUCT MEASUREMENTS

	XS	S	M	L	XL	2XL	3XL	4XL
Chest	18.5	20	21.5	23	24.5	26	28	30
Body Length	26	27	28	29	30	31	31.5	32
Sleeve Length	33.25	34	34.75	35.5	36.25	37	37.75	38.5

CHEST

Measured across the chest one inch below armhole when laid flat.

BODY LENGTH

Measured from high point of shoulder to finished hem at back.

SLEEVE LENGTH

Start at center of neck and measure down shoulder, down sleeve to hem.

SIZE CHART

	XS	S	M	L	XL	2XL	3XL	4XL
Chest	32-34	35-37	38-40	41-43	44-46	47-49	50-53	54-57

CHEST

With arms down at sides, measure around the upper body, under arms and over the fullest part of the chest.